Lab 14

Robin Meyler

1) Commands:

7za a tensorflow-master

7za – File archiver with highest compression ratio

tar -zcf tensor.tar.gz tensorflow-master

tar - GNU version of the tar archiving

z – gunzip

c – create

use an archive file

tar -jcf tensor.tar.bz2 tensorflow-master

j – bzip2

tar – GNU version of the tar archiving

tar -Zcf tensor.tar.Z tensorflow-master

Z – compress

tar - GNU version of the tar archiving

7za x tensorflow-master.7z

7za - File archiver with highest compression ratio

tar -Zxf tensor.tar.Z

x - extract

tar - GNU version of the tar archiving

tar -jxf tensor.tar.bz2

j – bzip2

tar - GNU version of the tar archiving

tar -zxf tensor.tar.gz

tar - GNU version of the tar archiving

2) Compression:

Let $A = \{a/20, b/15, c/5, d/15, e/45\}$


Huffman Encoding:

1st Pass:


2nd Pass:

3rd Pass:

4th Pass:



3) Delta Compression: Info Exchange chart



Ack 1 Ack 2 Client Server Server sends base Sends changes - ID 1 Receives changes ID 1 sends ACK Server sends changes since base, ID 2 Decompresses ID 1 with Base state Receives ACK 1 Received state changes ID 2 Sends changes since state 2: ID 3 Decompresses + Sends ACK 3 Get ACK 2 ACK 3 is lost! Sends changes since state 3; Lost! Doesn't get ACK 3, sends changes since state 3, ID 5 Decompresses ID 5 using state 3, sends ACK 5 Gets ACK 5, sends changes since state 5, ID 6

4) LZW Compression:

String:

BABAABAAA

A = 0, B = 1

BABAABAA

B – in dictionary

BA not, BA = 2

BABAABAAA

B – in dictionary

BA – in dictionary

BAA not, BAA = 4

BABAABAAA

A – in dictionary

AB – in dictionary

ABA not, ABA = 6

BABAABAAA

A – in dictionary

AA – in dictionary

AAA not, AAA = 8

BABAABAAA

A – in dictionary

AB not, AB = 3

BABAABAAA

A – in dictionary

AA not, AA = 5

BABAABAAA

B – in dictionary

BA – in dictionary

BAA not, BAA = 7